

GLOSSARY OF CUSHION FEATURES



Knife Edge

Made by sewing the top and bottom fabric panels together to make a more traditional sewing seam, which is located mid height on the sides of the cushion.



Boxed Edge

Constructed with a vertical sidewall that is the same height as the thickness of the cushion. They are made by assembling the top and bottom section of the cut fabric to the sidewall fabric to form a box.



Bullnose

Constructed where the top and bottom edges of the cushion are slightly rounded and do not show a seam. On seat cushions, there are seams at the side and back.



Self Welt

Constructed where a welt cord is covered in fabric and is sewn into the seams of the fabric around the edges of the cushion. It is on both seams on a boxed cushion.



Ties

Matching fabric ties can be inserted within the cushion's seams. These ties are often at the corner and at the hinge or fold of a cushion. They are used to easily secure your cushion to outdoor furniture.



Velcro

Velcro ties can be inserted within the cushion's seams. These ties are often at the corner, back and at the hinge or fold of a cushion. They are used to easily secure your cushion to outdoor furniture.



Button Tufted

Achieved by inserting either plastic or fabric covered buttons into the cushion. These buttons are tightly held together with a piece of outdoor grade string between them. By doing this, the cushion can be turned over for the same look on both sides. Inserted buttons will draw the fabric and cushion filling in for a tufted appearance.



Euro Tufted

Achieved with a top stitch added to give the cushion a tufted appearance. It brings the top and bottom layers together so the same look is on both sides of the cushion.